Flow Measurement SITRANS F M

MAG 8000 for abstraction and distribution network applications (7ME6810)

Overview



Benefits

Easy to install

- Compact or remote solution with factory mounted cable and customer setting from factory
- IP68/NEMA 6P enclosure. Sensor can be buried.
- Flexible power supply internal or external battery pack or mains power supply with battery back-up possibilities

Long-term stability/Low cost of ownership

- No moving parts in a robust construction means less wear and tear
- Basic and advanced transmitter versions with different optional add-on communication modules fulfil various customer requirements for high cost efficiency
- Up to 0.2 % maximum uncertainty
- Bi-directional measurement with an outstanding low flow performance
- Up to 10 years maintenance-free operation in typical applications

Intelligent information, easy to access

- Advanced information on site
- Advanced statistics and diagnostics
- Optional high-performance GSM/GPRS module offers an efficient solution for remote measurement and monitor via wireless communication.

Technical specifications

Meter	
Accuracy	Standard calibration:
	± 0.4 % of rate ± 2 mm/s Extended calibration
	DN 50 DN 300 (2" 12"): ± 0.2 % of rate ± 2 mm/s
Media conductivity	Clean water > 20 μs/cm
Temperature	00 00 (4 440 05)
Ambient Media	-20 +60 °C (-4 +140 °F) 0 70 °C (32 158 °F)
Storage	-40 +70 °C (-40 +158 °F)
Enclosure rating	IP68/NEMA 6P; Cable glands mounted requires Sylgard potting kit to remain IP68/NEMA 6P, otherwise IP67/NEMA 4 is obtained; Factory-mounted cable provides IP68/NEMA 6P
Certificates and approvals	
Calibration (standard) Drinking water approvals	2 x 25 % and 2 x 90 % • NSF/ANSI Standard 61 ¹⁾ (cold water) USA
	• WRAS (BS 6920 cold water) UK
	ACS Listed France
	DVGW W270 Germany D
	Belgaqua (B)MCERTS (GB)
Fire Service Approvals	FM Fire Service Meter
Conformity	(Class Number 1044) • PED: 97/23EC ²⁾
	For pressure/temperature curves see MAG 3100 on page 3/71.
	EMC: IEC/EN 61000-6-3, IEC/EN 61000-6-2
Sensor version	DN 25 1200 (1" 48")
Measuring principle	Electromagnetic induction
Excitation frequency	
Basic version	
Battery-powered	DN 25 150 (1" 6"): 1/15 Hz DN 200 600 (8" 24"): 1/30 Hz DN 700 1200 (28" 48"): 1/60 Hz
Mains-powered	DN 25 150 (1" 6"): 6.25 Hz DN 200 600 (8" 24"): 3.125 Hz
	DN 700 1200 (28" 48"): 1.5625 Hz
Advanced version	
Battery-powered	DN 25 150 (1" 6"): 1/15 Hz (adjustable up to 6.25 Hz; reduced battery lifetime)
	DN 200 600 (8" 24"): 1/30 Hz (adjustable up to 3.125 Hz; reduced battery lifetime)
	DN 700 1200 (28" 48"): 1/60 Hz (adjustable up to 1.5625 Hz; reduced battery lifetime)
Mains-powered	DN 25 150 (1" 6"): 6.25 Hz DN 200 600 (8" 24"): 3.125 Hz
	3.125 HZ DN 700 1200 (28" 48"): 1.5625 Hz

Flow Measurement SITRANS F M

MAG 8000 for abstraction and distribution network applications (7ME6810)

Flanges	
EN 1092-1 (DIN 2501)	DN 25 and DN 40 (1" and 1½"): PN 40 (580 psi)
	DN 50 150 (2" 6"): PN 16 (232 psi)
	DN 200 1200 (8" 48"): PN 10 or PN 16 (145 psi or 232 psi)
ANSI 16.5 Class 150	1" 24": 20 bar (290 psi)
AWWA C-207	28" 48": PN 10 (145 psi)
AS 4087	DN 50 1200 (2" 48"): PN 16 (232 psi)
Liner	EPDM
Electrode and grounding electrodes	Hastelloy C276/2.4819
Grounding straps	Grounding straps are premounted from the factory on each side of the sensor.

¹⁾ Including Annex F

²⁾ For further information on the PED standard and requirements see page 9/14.

Flow Measurement SITRANS F M

MAG 8000 for abstraction and distribution network applications (7ME6810)

Colection and Ordering date	Order No
Selection and Ordering data SITRANS F M MAG 8000 water meter	Order No. 7 ME 6 8 1 0 =
Diameter	
DN 25 (1")	2 D
DN 40 (1½") DN 50 (2")	2 R 2 Y
DN 65 (2½")	3 F
DN 80 (3")	3 M
DN 100 (4")	3 T
DN 125 (5")	4 B 4 H
DN 150 (6") DN 200 (8")	4 P
DN 250 (10")	4 V
DN 300 (12")	5 D
DN 350 (14")	5 K
DN 400 (16")	5 R 5 Y
DN 450 (18") DN 500 (20")	6 F
DN 600 (24")	6 P
DN 700 (28") ¹⁾	6 Y
DN 750 (30°) ¹⁾ DN 800 (32°) ¹⁾	7 D 7 H
DN 900 (36") ¹⁾	7 M
DN 1000 (40") ¹⁾	7 B
DN 1050 (42") ¹⁾	7 U
DN 1100 (44") ¹⁾	7 V
DN 1200 (48") ¹⁾	8 B
Flange norm and pressure rating EN 1092-1	
PN 10 (DN 200 1200 (8" 48"))	В
PN 16 (DN 50 1200 (2" 48"))	C
PN 16 non-PED (DN 700 1200 (28" 48")) PN 40 (DN 25 40 (1" 1½"))	D F
ANSI B16.5	
Class 150	J
<u>AWWA C-207</u> Class D (28" 48")	L
AS4087	
PN 16 (DN 50 1200 (2" 48"))	N
Sensor version	3
EPDM liner and Hastelloy electrodes	
Calibration Standard ± 0.4 % of rate ± 2 mm/s	
Extended ± 0.2 % of rate ± 2 mm/s DN 25 300	1 2
(1" 12")	
Region version	
Europe (m ³ , m ³ /h, 50 Hz) USA (Gallon, GPM, 60 Hz)	1
Australia (MI, MI/d, 50 Hz)	2 3
Transmitter type and installation	
Basic version integral on sensor	A
Basic version remote, cable mounted on sensor	
with IP68/NEMA 6P plugs: • 5 m (16.4 ft)	В
• 10 m (32.8 ft)	c
• 20 m (65.6 ft)	D
30 m (98.4 ft) Advanced version integral on sensor	E
Advanced version integral on sensor Advanced version remote, cable mounted on	K
sensor with IP68/NEMA 6P plugs:	
• 5 m (16.4 ft)	L M
• 10 m (32.8 ft) • 20 m (65.6 ft)	N N
• 30 m (98.4 ft)	P

Selection and Ordering data	Order No.	
SITRANS F M MAG 8000 water meter	7 M E 6 8 1 0 -	
Communication interface		
No additional "add-on" communication module installed	A	
Serial RS 485 with Modbus RTU (Terminated as end device)	В	
Serial RS 232 with Modbus RTU	С	
GSM/GPRS communication module with remote antenna; 5 m (16.4 ft) cable	S	
GSM/GPRS communication module with analog inputs and remote antenna; 5 m (16.4 ft) cable	Т	
Power supply		
Internal battery (no battery included) Internal battery pack installed ²⁾	0	
Power cable (1.5 m (4.9 ft)) with IP68/NEMA 6P plugs for external battery (no battery included)	2	
12/24 V AC/DC power supply with battery backup and 3 m (9.8 ft) power cable for external connec- tion (no battery included)	3	
115 230 V AC power supply with battery backup and 3 m (9.8 ft) power cable for external connection (no battery included)	4	
		f

 $^{^{1)}\,}$ The Diameter DN 700 (28") to DN 1200 (48") is only available as $\underline{\text{remote}}$ transmitter type installation.

Operating instructions for SITRANS F M MAG 8000

Description	Order No.	
• English	A5E03071515	
• German	A5E00740986	
• Spanish	A5E00741031	
• French	A5E00741021	

This device is shipped with a Quick Start guide and a CD containing further SITRANS ${\sf F}$ literature.

All literature is also available for free at: http://www.siemens.com/flowdocumentation

Operating instructions for MAG 8000 GSM/GPRS communication module

Description	Order No.	
• English	A5E03644134	

transmitter type installation.

Lithium batteries are subject to special transportation regulations according to United Nations "Regulation of Dangerous Goods, UN 3090 and UN 3091". Special transport documentation is required to observe these regulations. This may influence both transport time and costs.

Flow Measurement SITRANS F M

MAG 8000 for abstraction and distribution network applications (7ME6810)

Selection and Ordering data	Order code
Additional information	
Please add "-Z" to Order No. and specify Order code(s) and plain text.	
Flow unit	
l/s	L00
MGD	L01
CFS	L02
l/min	L03
m³/min GPM	L04 L05
CFM	L06
I/h	L07
m ³ /h	L08
GPH	L09
CFH	L10
GPS	L11
MI/d m ³ /d	L12 L13
GPD	L14
Totalizer	-
Volume calculation (default totalizer 1= forward and totalizer 2 = reverse)	
Totalizer 1 = RV, reverse flow	L20
Totalizer 1 = NET, net flow	L22
Totalizer 2 = FW, forward flow Totalizer 2 = NET, net flow	L30 L31
Volume unit	LSI
m ³	1.40
MI	L40 L41
G	L42
AF	L43
I x 100	L44
m ³ x 100	L45
G x 100 CF x 100	L46 L47
MG	L48
G x 1000	L49
CF x 1000	L50
Al	L51
kl	L52
<u>Pulse set up</u> (default pulse A= forward and pulse B = Alarm)	
A function = RV, reverse flow	L62
A function = FWnet, forward net flow	L63
A function = RVnet, reverse net flow	L64
A function = Off	L65
Volume per pulse A = x 0.0001 Volume per pulse A = x 0.001	L70 L71
Volume per pulse $A = x 0.001$	L72
Volume per pulse $A = x \cdot 0.1$	L73
Volume per pulse A = x 1	L74
B function = FW, forward flow	L80
B function = RV, verse flow B function = FWnet, forward net flow	L81 L82
B function = RVnet, forward fiet flow	L83
B function = Alarm	L84
B function = Call up	L85
Volume per pulse $B = x 0.0001$	L90
Volume per pulse B = x 0.001	L91
Volume per pulse B = x 0.01	L92
Volume per pulse B = x 0.1 Volume per pulse B = x 1	L93 L94
Agricule her harse n = x 1	L34

Selection and Ordering data	Order code
Additional information	
Please add "-Z" to Order No. and specify Order code(s) and plain text.	
Data logger set up (default month logging)	
DataloggerInterval = Daily DataloggerInterval = Weekly	M31 M32
Factory mounted cables	
5 m (16.4 ft) pulse cable A+B 5 m (16.4 ft) communication cable RS 232/RS 485 terminated as end device	M81 M82
20 m (65.6 ft) pulse cable A+B 20 m (65.6 ft) communication cable RS 232/RS 485 terminated as end device	M84 M85
Cello 2 channel, input cable 3 m (9.84 ft) with Brad Harrison micro-change 3 way connector	M87
Cello 2 channel, input cable 5 m (16.4 ft) with MIL-C-26482 spec. connectors	M89
SOFREL data logger cable 2 m with connector for SOFREL GSM module	M92
FM Fire Service Approval (with ANSI B16.5 Class 150 flanges) DN 50, DN 80 and DN 100 (2", 3" and 4") DN 150 and DN 200 (6" and 8") DN 250 and DN 300 (10" and 12")	P20 P21 P22